

Service Manual

Speaker System

Model No. SB-MAX370GS

Product Color : (K)... Black Type

Simplified

**Note: Please use this manual together with service manual
Model No.[SB-MAX370PUK, Order No. PSG1402008CE]**

⚠ WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

1 Different Points

1.1. Mechanical Replacement Part List

Ref. No.	Parts No.		Parts name & Description	Qty	Remarks
	SB-MAX370PUK	SB-MAX370GSK			
2	RYQ1360-K	RYQ1360B-K	SPEAKER CABINET ASS'Y L	1	
2	RYQ1360A-K	RYQ1360C-K	SPEAKER CABINET ASS'Y R	1	
3	RGN3433-K	RGN3463-K	SPEC LABEL L	1	
3	RGN3433A-K	RGN3463A-K	SPEC LABEL R	1	
22	RYQ1441-K	RYQ1441A-K	SPEAKER CABINET ASS'Y	1	
26	RGN3434-K	RGN3461-K	SPEC LABEL L	1	
26	RGN3434A-K	RGN3461A-K	SPEC LABEL R	1	
42	RYQ1441B-K	RYQ1441C-K	SPEAKER CABINET ASS'Y	1	
46	RGN3435-K	RGN3462-K	SPEC LABEL L	1	
46	RGN3435A-K	RGN3462A-K	SPEC LABEL R	1	
P1	RPG0K16	RPG0K18	PACKING CASE	1	
P3	RPF0572-1	RPF0572B-1	MIRAMAT BAG	2	
P4	RPF0573-1	RPF0573C-1	MIRAMAT BAG	2	
P5	RPF0726	RPF0726A	MIRAMAT	2	

IPSG1404

Panasonic®

© Panasonic Corporation 2014. All rights reserved.
Unauthorized copying and distribution is a violation of law.