

# Service Manual

Epilator

Model No. **ES-ED64**



USA

## **⚠ WARNING**

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

## **IMPORTANT SAFETY NOTICE**

There are special components used in this equipment which are important for safety. These parts are marked by **⚠** in the Schematic Diagrams, Circuit Board Diagrams, Exploded Views and Replacement Parts List. It is essential that these critical parts should be replaced with manufacturer's specified parts to prevent shock, fire or other hazards. Do not modify the original design without permission of manufacturer.

## **TABLE OF CONTENTS**


	PAGE
<b>1 EXPLODED VIEW &amp; REPLACEMENT PARTS LIST</b>	<b>2</b>
1.1. EXPLODED VIEW	2
1.2. REPLACEMENT PARTS LIST	3

**Panasonic®**

© Panasonic Corporation 2014  
Unauthorized copying and distribution is a violation of law.

# 1 Exploded View and Replacement Parts List

## 1.1. EXPLODED VIEW



## 1.2. REPLACEMENT PARTS LIST

Safety	Ref. No.	Part No.	Part Name & Description	Quantity	Remarks
	1	WESED90X7158	PROTECTION CAP	1	
	2	WESED90P3128	FAST CAP	1	
	3	WESED90P3108	GENTLE CAP	1	
	4	WESED90W1068	EPILATION HEAD FOR LEGS/ARMS	1	
	5	WESED90X7168	PROTECTION CAP	1	
	6	WESED90W3128	EPILATION HEAD FRAME	1	
	7	WESED90W1078	EPILATION HEAD FOR UNDERARMS	1	
	8	WESWD94X7158	PROTECTION CAP	1	
	9	WESED94W1078	BRUSH	1	
	10	WESED94W4068	BRUSH HEADED	1	
	11	WESED90W7658	POWER ADAPTOR	1	A-2 PLUG
	12	WES2047H6767	CLEANING BRUSH	1	
	-	WESED64S8008	INDIVIDUAL BOX	1	
	-	WESED64S8108	OPERATING INSTRUCTIONS	1	