


EXPLODE VIEW



IMPORTANT SAFETY NOTICE

REPLACEMENT PARTS LIST

Components identified by "☼" mark have special characteristics important for safety. When replacing any of these components, use only manufacture's specified parts. If something abnormal discovered before using, please be quick to contact service agent.

REF. NO.	PART NAME	PART NO.	Q'TY /SET	REMARKS
☼ 1	Soleplate assembly	ANI1064PN97K	1	India/Nigeria
		ANI1064QN97K	1	Peru/Bolivia/Uruguay/Bengal/Cambodia/Myanmar / Sri Lanka/Brunei/Tanzania/Sudan/Yemen/Angolan
		ANI1070QN97K	1	Indonesia
2	Terminal screw (Power cord)	ANI9009-665	3	India/Nigeria
			2	The others
☼ 3	Indicator light assembly	ANI5600-N97	1	
4	Terminal screw (Indicator light)	ANI9009-A43	2	
5	Packing (B)	ANI1471-N55K	1	Indonesia
		ANI1471-A76	1	The others
6	Spacer	ANI2350-352	3	
7	Heat-insulated plate	ANI2340-N97K	1	
8	Heat-insulated plate screw	XTV4+20JFN	3	
9	Handle(Tank) assembly	ANI2000N979L	1	NI-V100N-A(Blue)
		ANI2000N978U	1	NI-V100N-P(Pink)
10	Handle screw(A)	XTN4+16BFN	1	
11	Handle screw(B)	XTW4+16EFN	2	
12	Temperature select dial	ANI2186-N97X	1	
13	Valve steam assembly	ANI1850NN97	1	Indonesia
		ANI1850-N97	1	The others
14	Lock button	ANI2120-A00	1	
15	Handle cover	ANI2060NN97X	1	Indonesia
		ANI2060-N97X	1	The others
16	Steam button	ANI2100N978L	1	NI-V100N-A(Blue)
		ANI2100N977U	1	NI-V100N-P(Pink)
17	Cord bushing	ANI4646M89XS	1	
18	Bear burning fiber	ANI2351-N97K	1	
19	Fixed board of the cord	ANI4663-N97	1	
20	Fixed board screw	XTN3+14BFN	1	
21	Handle cover screw	ANI9021-N97	2	
☼ 22	Cord assembly	ANI4454-N97	1	India
		ANI4440-N97	1	Nigeria
		ANI4421-N97	1	The others