

Parts Change Notice

Model No. MK-GH1WTN MK-GB1WTM

Subject : Parts number correction.

Please revise the original parts list in the Service Manual to conform to the change(s) shown herein.
If new part numbers are shown, be sure to use them when ordering parts.

Reason for Change

*The circled item indicates the reason. If no marking, see the Notes in the bottom column.

1. Improve performance	
2. Change of material or dimension	
3. To meet approved specification	
4. Standardization	
5. Addition	
6. Deletion	
v 7. Correction	
8. Other	

Interchangeability Code

**The circled item indicates the interchangeability. If no marking, see the Notes in the bottom column.

Parts	Set Production	
A Original New	→ Early → Late	Original or new parts may be used in early or late production set. Use original parts until exhausted, then stock new parts.
B Original New	→ Early → Late	Original parts may be used in early production sets only. New parts may be used in early or late production sets. Use original parts where possible, then stock new parts.
V C Original New	→ Early → Late	New parts only may be used in early or late production sets. Stock new parts.
D Original New	→ Early → Late	Original parts may be used in early production sets only. New parts may be used in late production sets only. Stock both original and new parts.
E Other		

Part Number

Model No.	Ref. No.	Original Part No.	New Part No.	Notes	Part Name & Descriptions
MK-GH1WTN	1	AMA00Z130-00S	AMA00Z13000S	7C	Mixer A'ssy
MK-GB1WTN	1	AMA00Z127-00S	AMA00Z12700S	7C	Mixer A'ssy

File this Parts Change Notice with your copy of the Service Manual.

Panasonic

© Panasonic Corporation 2012 Unauthorized copying and distribution is a violation of law.